



INSTRUCTIONS

1. Remove cover (from new shoes) to expose cleat mounting holes; unscrew the screw with a 4mm allen key, then pull the cover off with pliers.



2. Line up the bolts and washers (as shown), and attach the cleats tightly to the slots on the sole of each shoe with the included allen key. The cleats should be attached slightly lower relative to the ball of your foot, about 1/4". You can adjust the cleats forward, back, and side to side on the sole of the shoe to suit your riding preference.



NOTES

1. Do not use the shoes for walking with the cleats attached.
2. Make sure to reattach the cover with the bolts when using the shoes for other activities .
3. Avoid using shoes on rugged surfaces as the soles are made from a special material.
4. Do not use washing machines or dryers to clean the shoes.
5. Allow your shoes to air dry in a shaded area. Do not expose to direct sunlight.

SAFETY INFORMATION AND WARNINGS

TO AVOID SERIOUS INJURIES:

- Practice using the locking mechanism before you ride to make sure it is seating properly.
- Before riding, place one foot on the ground and practice engaging and disengaging from the pedal a number of times until you get used to it.
- If you do not maintain both your shoes and cleats in good condition, release and engagement to the pedals could become unpredictable or difficult, which could result in injury.
- SPD-SL shoes may not provide adequate traction for walking on wet and/or smooth surfaces. Be careful when walking on such surfaces in order to avoid a serious injury.
- Select the right size shoes for your feet, and be sure to secure the loop & hook fasteners and/or buckles when wearing them.
- Loose, worn, or damaged parts may cause serious injury to the rider. We strongly recommend only using Echelon® replacement parts.
- If you have any questions regarding methods of installation, adjustment, maintenance or operation, please contact Echelon® at cs@echelonfit.uk.
- Read these Technical Service Instructions carefully, and keep them in a safe place for later reference.

BE SURE TO READ AND FOLLOW THE ABOVE WARNINGS CAREFULLY.

IF THE WARNINGS ARE NOT FOLLOWED, YOUR SHOES MAY NOT COME OUT OF THE PEDALS WHEN YOU INTEND OR THEY MAY COME OUT UNEXPECTEDLY OR ACCIDENTALLY, AND SEVERE INJURY MAY RESULT.